



TRANSPORTER



I


ESPLOSO RICAMBI

GB

EXPLODED VIEW

90906
TAG500TDH

DUMPER 90906 TAG500TDH



MINI TRACKED DUMPER

TRANSPORTER 90906 TAG500TDH

Pos.	Art. AMA	OEM	Description	Quant.
1	TCT-0001-TDH	09745.10.124	Valve Lever	4
2	TCT-0002-TDH	6170_M8	Nut M8	4
3	TCT-0003-TDH	95_8_100HV	Washer 8	35
4	TCT-0004-TDH	93_8_BX	Washer 8	22
5	TCT-0005-TDH	09745.10.011	Handle	1
6	TCT-0006-TDH	16674.1_M8x20_8.8	Bolt M8x20	4
7	TCT-0007-TDH	09745.10.900	Throttle Controller	1
8	TCT-0008-TDH	5783_M6x16_8.8	Bolt M6x16	6
9	TCT-0009-TDH	95_6_100HV	Washer 6	13
10	TCT-0010-TDH	889.1_M6_8	Nut M6	12
11	TCT-0011-TDH	09745.10.140	Throttle Mounting Plate	1
12	TCT-0012-TDH	5783_M6x30_8.8	Bolt M6x30	2
13	TCT-0013-TDH	09745.30.030	Parking Cable	1
14	TCT-0014-TDH	09745.10.114	Front Guard	1
15	TCT-0015-TDH	16674.1_M6x12_8.8	Bolt M6x12	14
16	TCT-0016-TDH	16674.1_M8x16_8.8	Bolt M8x16	4
17	TCT-0017-TDH	09745.10.125	Top & Side Guard	1
18	TCT-0018-TDH	889.1_M8_8	Nut M8	21
19	TCT-0019-TDH	5783_M8x20_8.8	Bolt M8x20	4
20	TCT-0020-TDH	7271.1_M8x25	Ball Knob M8x25	1
21	TCT-0021-TDH	09745.10.126	Cable Fixing Bolt	1
22	TCT-0022-TDH	5783_M6x20_8.8	Bolt M6x20	2
23	TCT-0023-TDH	09640.10.116	Subplate for Parking Lever	1
24	TCT-0024-TDH	09745.10.013	Parking Lever	1
25	TCT-0025-TDH	91_2x12	Cotter Pin 2x12	1
26	TCT-0026-TDH	09745.10.121	Rotating Shaft	1
27	TCT-0027-TDH	09745.10.010	Operation Frame	1
28	TCT-0028-TDH	5783_M6x50_8.8	Bolt M6x50	2
29	TCT-0029-TDH	09745.00.996	Ball Valve	1
30	TCT-0030-TDH	09640.10.102	Valve Bracket	1
31	TCT-0031-TDH	09745.10.127	Valve Lever Connecting Sleeve	4
32	TCT-0032-TDH	6177.1_M8_8	Nut M8	4
33	TCT-0033-TDH	09745.10.122	Valve Plate	1
34	TCT-0034-TDH	09745.00.110	Multi-way Valve 1	1
35	TCT-0035-TDH	5783_M8x45_8.8	Bolt M8x45	4
36	TCT-0036-TDH	09745.00.111	Multi-way Valve 2	1
37	TCT-0037-TDH	5783_M8x65_8.8	Bolt M8x65	2
38	TCT-0038-TDH	65916.00.023	Manual Storage Cylinder	1
39	TCT-0039-TDH	09745.10.107	Rear Guard	1
40	TCT-0040-TDH	889.1_M12_8	Nut M12	14
41	TCT-0041-TDH	95_12_100HV	Flat Washer 12	16
42	TCT-0042-TDH	09745.50.112-2	Bush	2

43	TCT-0043-TDH	5783_M12x35_8.8	Bolt M12x35	2
44	TCT-0044-TDH	09745.50.134	Rotating Pin	1
45	TCT-0045-TDH	09710.20.328	Reset Spring	1
46	TCT-0046-TDH	09745.00.112	Pull Ring	1
47	TCT-0047-TDH	09745.50.021	Driving Platform	1
48	TCT-0048-TDH	5783_M8x25_8.8	Bolt M8x25	2
49	TCT-0049-TDH	09745.30.203	Large Washer	2
50	TCT-0050-TDH	09745.30.021-2	Driving Wheel	2
51	TCT-0051-TDH	5783_M12x50_8.8	Bolt M12x50	8
53	TCT-0052-TDH	09745.00.108	Parking Shaft 1	2
54	TCT-0053-TDH	09745.30.153	Spring	2
55	TCT-0054-TDH	894.1_14_YH	Circlip 14	2
56	TCT-0055-TDH	09745.30.010-2	Chassis	1
57	TCT-0056-TDH	09745.30.204	Parking Connecting Part	1
58	TCT-0057-TDH	93_6_BX	Washer 6	2
59	TCT-0058-TDH	889.1_M10_8	Nut M10	12
60	TCT-0059-TDH	95_10_100HV	Flat Washer 10	12
61	TCT-0060-TDH	5783_M10x30_8.8	Bolt M10x30	8
62	TCT-0061-TDH	09745.30.020	Rubber Mat	2
63	TCT-0062-TDH	276_6204-2RS	Bearing 6204-2RS	12
64	TCT-0063-TDH	13871_FB25x47x7	Oil Seal FB 25x47x7	6
65	TCT-0064-TDH	09710.65.001	Track Roller	6
66	TCT-0065-TDH	96.2_10_100HV	Wide Washer 10	8
67	TCT-0066-TDH	1972_10_YH	Wing Washer	6
68	TCT-0067-TDH	09735.00.106	Stud Bolt	4
69	TCT-0068-TDH	5783_M10x25_8.8_YH	Bolt M10x25	4
70	TCT-0069-TDH	09710.00.118	Axle Cap	2
71	TCT-0070-TDH	09745.00.102-2	Left Guard Plate	1
72	TCT-0071-TDH	09745.00.103-2	Right Guard Plate	1
73	TCT-0072-TDH	09745.00.105	Elastic Cushion	2
74	TCT-0073-TDH	74109.00.304	R-Clip	2
75	TCT-0074-TDH	09745.00.116	Pivot Shaft	1
76	TCT-0075-TDH	5783_M16x70_8.8_BX	Bolt M16x70	2
77	TCT-0076-TDH	6170_M16	Nut M16	2
78	TCT-0077-TDH	09745.30.115	Spring Locating Bush	2
79	TCT-0078-TDH	40x80x6	Spring 40x80x6	2
80	TCT-0079-TDH	276_61905-2RS	Bearing 61905-2RS	4
81	TCT-0080-TDH	893.1_42_YH	Circlip 42	4
82	TCT-0081-TDH	09710.00.123	φ 42 Axle End Cap	2
83	TCT-0082-TDH	93_10_BX	Washer 10	2
84	TCT-0083-TDH	09720.55.101	Guiding Wheel	2
85	TCT-0084-TDH	13871_FB30x42x7	Oil Seal FB 30x42x7	2
86	TCT-0085-TDH	09745.30.022	Guide Wheel Axle	1
87	TCT-0086-TDH	09745.30.011-2	Rear Cover	1
88	TCT-0087-TDH	5782_M8x110_8.8	Bolt M8x110	2

89	TCT-0088-TDH	09720.00.101	Rubber Track (37)	2
90	TCT-0089-TDH	G270F-9HP	Gasoline Engine	1
91	TCT-0090-TDH	5783_M8x35_8.8	Bolt M8x35	4
92	TCT-0091-TDH	96.2_8_100HV	Wide Washer 8	4
93	TCT-0092-TDH	09745.00.108	Rubber Damper	4
94	TCT-0093-TDH	77_M8x10_8.8_YH	Screw M8x10	6
95	TCT-0094-TDH	09735.27.122	Coupler Gasket	1
96	TCT-0095-TDH	1096_B7x22	Key B7x22	1
97	TCT-0096-TDH	09745.40.102-2	Spacer Bush	1
98	TCT-0097-TDH	09745.40.112-2	Coupler (R)	1
99	TCT-0098-TDH	09745.40.111	Coupler (L)	1
100	TCT-0099-TDH	09745.40.010-2	Connecting Flange	1
101	TCT-0100-TDH	5783_M8x25_8.8	Bolt M8x25	4
102	TCT-0101-TDH	09745.60.121-2	Elbow Connector For Pump Outlet	2
103	TCT-0102-TDH	CBQZ-G-4.2/4.2-00	Gear Pump	1
104	TCT-0103-TDH	70.1_M8x180_8.8_YH	Screw M8x180	2
105	TCT-0104-TDH	09745.60.119-2	Straight Connector for Pump Inlet	1
106	TCT-0105-TDH	09745.60.120-2	Elbow Connector For Pump Inlet	1
107	TCT-0106-TDH	09745.60.125-2	Pump Outlet Hose (Short)	1
108	TCT-0107-TDH	09745.60.126-2	Pump Outlet Hose (Long)	1
109	TCT-0108-TDH	09745.60.124-2	Oil Suction Hose (Long)	1
110	TCT-0109-TDH	09745.60.123-2	Oil Suction Hose (Short)	1
111	TCT-0110-TDH	09745.60.127-3	Oil Return Hose (Short)	1
112	TCT-0111-TDH	09745.60.128-3	Oil Return Hose (Long)	1
113	TCT-0112-TDH	09745.60.139-3	T-connector M26x1.5	1
114	TCT-0113-TDH	09745.60.138-3	Oil Return Connector	1
115	TCT-0114-TDH	09745.30.130	Oil Dipstick	1
116	TCT-0115-TDH	982_27	Combined Sealing Washer 27	1
117	TCT-0116-TDH	16674.1_M6x16_8.8	Flange Bolt M6x16	8
118	TCT-0117-TDH	09745.30.014	Tank Cover	1
119	TCT-0118-TDH	09745.30.141	Paper Gasket	1
120	TCT-0119-TDH	09745.30.162	Union	2
121	TCT-0120-TDH	09745.30.130	Oil Filter Connector	2
122	TCT-0121-TDH	09745.00.050	Oil Filter M27x2	2
123	TCT-0122-TDH	5783_M8x16_8.8	Bolt M8x16	4
124	TCT-0123-TDH	09745.30.013	Oil Tank	1
125	TCT-0124-TDH	09745.30.163	Screwed Plug	1
126	TCT-0125-TDH	09745.60.103-2	Oil Return Pipe 1 for Tipping Bucket	1
127	TCT-0126-TDH	09745.60.101-2	Oil Return Pipe 1 for Shovel	1
128	TCT-0127-TDH	09745.60.112-2	90° Elbow Connector	4
129	TCT-0128-TDH	09745.60.113-2	Throttle Valve Connector	4
130	TCT-0129-TDH	KC-03 3/8"	One-way Throttle Valve	2
131	TCT-0130-TDH	09745.60.105-2	Oil Inlet Pipe for Tipping Bucket	1
132	TCT-0131-TDH	09745.60.111-2	T-connector M18x1.5	2
133	TCT-0132-TDH	09745.60.102-2	Oil Return Pipe 2 for Tipping Bucket	1

134	TCT-0133-TDH	09745.60.118-2	Hose Clamp	8
135	TCT-0134-TDH	09745.60.136-2	Oil Inlet Hose For Tipping Cylinder	1
136	TCT-0135-TDH	09745.60.104-2	Oil Return Pipe 2 for Shovel	1
137	TCT-0136-TDH	09745.60.117-2	Elbow Connector	2
138	TCT-0137-TDH	09745.60.116-2	Straight Connector	2
139	TCT-0138-TDH	09745.60.114-2	Cylinder Connector	6
140	TCT-0139-TDH	09745.60.141-2	Oil Outlet Hose For Tipping Cylinder	1
141	TCT-0140-TDH	882_16x100_BX	Pin B16x100	1
142	TCT-0141-TDH	74109.00.102	R- Clip	6
143	TCT-0142-TDH	09745.00.010	Tipping Cylinder	1
144	TCT-0143-TDH	882_16x80_BX	Pin B16x80	4
145	TCT-0144-TDH	09745.91.010	Shovel Cylinder	2
146	TCT-0145-TDH	882_16x60_BX	Pin B16x60	2
147	TCT-0146-TDH	VU-10-G3/8"	One-way Valve	1
148	TCT-0147-TDH	09745.91.011	Left Connecting Rod	1
149	TCT-0148-TDH	09745.60.135-2	Connecting Hose for Shovel	1
150	TCT-0149-TDH	09745.60.115-2	T-connector M14x1.5	2
151	TCT-0150-TDH	09745.60.106-2	Oil Inlet Pipe 2 for Ball Valve	1
152	TCT-0151-TDH	7940.1_M6	Oil Nipple M6	6
153	TCT-0152-TDH	09745.60.109-2	Multi-way Valve Connector	14
154	TCT-0153-TDH	09745.60.134-2	Oil Inlet Hose for Shovel	1
155	TCT-0154-TDH	09745.60.133-2	Oil outlet Hose for Shovel	1
156	TCT-0155-TDH	91_4x35_BX	Cotter Pin 4x35	2
157	TCT-0156-TDH	09745.91.013	Right Connecting Rod	1
158	TCT-0157-TDH	5783_M12x40_8.8	Bolt M12x40	4
159	TCT-0158-TDH	09745.60.110-2	Motor Connector	5
160	TCT-0159-TDH	09745.60.108-2	Oil Inlet Pipe 1 for Shovel	1
161	TCT-0160-TDH	09745.91.012	Self- Loading Shovel	1
162	TCT-0161-TDH	09745.60.132-2	Motor Hose 4	1
163	TCT-0162-TDH	09745.60.131-2	Motor Hose 3	1
164	TCT-0163-TDH	09745.60.130-2	Motor Hose 2	1
165	TCT-0164-TDH	09745.60.129-2	Motor Hose 1	1
166	TCT-0165-TDH	09745.60.107-2	Oil Inlet Pipe for Ball Valve	1
167	TCT-0166-TDH	09745.60.122-2	Connecting Hose	1
168	TCT-0167-TDH	1972_8_YH	Wing Washer 8	2
169	TCT-0168-TDH	BM5-125	Hydraulic Motor	2
170	TCT-0169-TDH	882_16x140_BX	Pin B16x140	1
171	TCT-0170-TDH	09745.60.143-2	Connecting Hose 2 for Shovel	1
172	TCT-0171-TDH	09745.21.001	Hopper	1
173	TCT-0172-TDH	09745.60.144-2	Oil Return Pipe for Ball Valve	1